


Tappeti - Carpets - Tapis - Teppiche



TECHNICAL INFORMATION

Carpet Eikon

Composition: 60% Wool, 20% Cotton, 20% Viscose
Maintenance: only in specialized centers.

Carpet Carter

Composition: 100% Viscose
Maintenance: 30° water wash. Domestic washing is not recommended, wash only in specialized centers.

Carpet Mellow

Composition: 100% PES
Maintenance: only in specialized centers.

Carpet Nolan

Composition: 100% Viscose
Maintenance: vacuum regularly, wash only in specialized centers, do not use chemical cleaners, avoid excessive exposure to sunlight.

Carpet Nippon Rock

Composition: 100% Polyamide, bottom 100% Polyester
Maintenance: only in specialized centers. To uniform wear, turn the carpet regularly. Exposure to direct, continuous sunlight may change colors.

Carpet West

Composition: 60% Wool, 20% Cotton, 20% Viscose
Maintenance: Vacuum cleaner only; for the first months it's advised to use it often to avoid fluff. The use of carpet cleaner it is not recommended. Any threads escaping from the surface must be cut with scissors, pulling them could damage the carpet. Domestic washing is not recommended, wash only in specialized centers.

Carpets Scratch and waves

Carpets made in jacquard weaving, composition 100% cotton and anti-slip natural latex bottom.

Carpet OVERLAP

Composizione: 80% Bamboo, 20% Cotton
Hand tufted carpet.
Maintenance: specialized centers only.

Daily maintenance

Frequent use of the vacuum cleaner removes dirt particles from the surface before they enter in the fleece. Clean more carefully the area adjacent to the furniture legs, where dust accumulates the most. Liquid accidentally spilled on the carpet can act as a magnet for dirt making it appear on the surface of the carpet causing a dark stain. For the daily cleaning of the carpet we recommend the use of a medium power vacuum cleaner, the use of a vacuum cleaner with brushes or carpet cleaner damages the fleece. The strong action exerted by the vacuum cleaner extracts the dirt accumulated between the fibers. Any threads that protrude from the surface must be cut with scissors. It is recommended not to pull the threads. The carpets are shipped rolled up, so it is normal that as soon as they are opened they may have wrinkles, folds or a flattened fleece; this effect will disappear within a few weeks of laying. A light suction can promote relaxation of the fibers.

INFORMATIONS TECHNIQUES

Tapis Eikon

Composition: 60% Laine, 20% Coton, 20% Viscose
Entretien: laver uniquement dans des centres spécialisés.

Tapis Carter

Composition: 100% Viscose
Entretien: lavage à l'eau à 30°. Le lavage domestique n'est pas recommandé, laver uniquement dans des centres spécialisés.

Tapis Mellow

Composition: 100% PES
Entretien: laver uniquement dans des centres spécialisés.

Tapis Nolan

Composition: 100% Viscose
Entretien: laver uniquement dans des centres spécialisés. Pour une tenue uniforme, tourner le tapis régulièrement. Eviter l'excessive exposition à la lumière du soleil.

Tapis Nippon Rock

Composition: 100% Polyamide, bottom 100% Polyester
Entretien: laver uniquement dans des centres spécialisés. Pour une tenue uniforme, tourner le tapis régulièrement. Une exposition directe et continue à la lumière du soleil peut changer les couleurs.

Tapis West

Composition: 60% Laine, 20% Coton, 20% Viscose
Entretien: Aspirateur; pour les premiers mois c'est conseillé de l'utiliser souvent pour éviter la formation de duvet. Ce n'est pas conseillé d'utiliser un nettoyeur de tapis. En cas de fils qui s'échappent de la surface ils doivent être coupés avec des ciseaux, les tirer pourrait endommager le tapis. Le lavage domestique n'est pas recommandé, laver uniquement dans des centres spécialisés.

Tapiss Scratch e waves

Tapis réalisés en tissage jacquard, composition 100% coton avec fond en latex naturel antidérapant.

Tapis OVERLAP

Composizione: 80% Bamboo, 20% Coton
Tapis tufté à la main.
Entretien: dans des centres spécialisés.

Entretien quotidienne

L'utilisation fréquente de l'aspirateur élimine les particules de saleté de la surface avant qu'elles ne pénètrent dans la toison. Nettoyez plus soigneusement la zone adjacente aux pieds du meuble, là où la poussière s'accumule le plus. Le liquide renversé accidentellement sur le tapis peut agir comme un aimant pour la saleté, la faisant apparaître sur la surface du tapis, provoquant une tache foncée. Pour le nettoyage quotidien du tapis, nous recommandons l'utilisation d'un aspirateur de puissance moyenne, l'utilisation d'un aspirateur avec des brosses ou un nettoyeur de tapis endommage la toison. L'action forte exercée par l'aspirateur extrait la saleté accumulée entre les fibres. Tous les fils qui dépassent de la surface doivent être coupés avec des ciseaux. Il est recommandé de ne pas tirer les fils. Les tapis sont expédiés enroulés, il est donc normal que dès qu'ils sont ouverts, ils peuvent avoir des plis ou une toison aplatie; cet effet disparaîtra quelques semaines après de la pose. Une légère aspiration peut favoriser la relaxation des fibres.